

AUBO i5 Robot Joint Replacement Manual

Joint 6

Version 1.1

1. Operation Target Description



Figure 1. AUBO i5 Robot

2. Tools for Operation

1



1. 2mm Slotted Screwdriver

2



2. Tweezers

3



3. 5.5 mm Open-end Wrench


4



4. 2.5mm Allen Wrench

Figure 2. Tools

3. Safety Instructions



Warning

Warning: Before replacing any components in the control board, it is very important to shut down the system completely and cut off the power supply.



Caution

Caution: The cable socket is plugged in tightly, please pay attention when plugging and unplugging to ensure do not damage the interface board and the circuit.


4. Disassembly Procedures (End-Effector)



Figure 3,4. Overview of Joint 1-joint 2 junction

1. Use tweezers to pick up and pull rubber band to one side at joint 3;
2. Use 2.5mm Allen wrench to unscrew limit screw
3. Use 5.5mm Open-end Wrench to loose (just loose, don't unscrew them down)bolts at the junction. (Ten bolts in total)

4. Disassembly Procedures (End-Effector)



4. Once ten bolts are loose, pull the end-effector out a little bit, then twist it;


*, **: The existence of groove and protrusion is the reason for step 4 to pull the end-effector before twist it.

5. Gently place the end-effector to horizontal. Then, unplug the power cable connector (1) and the CANBUS cable connector (2).



Figure 5,6. Overview of Joint 6 and end-effector

4. Disassembly Procedures (End-Effector)




Regular End-effector

Figure 7,8,9. Joint 6 and end - effector

End-Effector Removal Complete
Next step, Joint 6 removal



4. Disassembly Procedures (Joint 6)



1. Use 2.5mm Allen wrench to unscrew screws no. 1 to no.3.
2. Use 2.5mm Allen wrench to unscrew limit screw no. 4.
3. Remove the Joint back case

Figure 10. Overview of Joint 6 (with back case)

4. Disassembly Procedures (Joint 6)





4. 2mm Slotted Screwdriver loosen two power cables and unplug them gently.
5. Unplug the CANBUS connector. (See figure 12)

Note: Joint internal design may vary according to the joint's hardware version, but its assembly is pretty much the same.

Figure 11,12. Overview of Joint 6 (without back case)


4. Disassembly Procedures (Joint 6)



6. Use tweezers to pick up and pull rubber band to one side at joint 6;
7. Use 5.5mm Open-end Wrench to loose (just loose, don't unscrew them down) bolts at the junction. (Ten bolts in total)

Figure 13, 14. Sideview of Joint 6 (without back case)

4. Disassembly Procedures (Joint 6)



11. Once ten bolts are loose, pull the end-effector out a little bit, then twist it;
12. Lift the joint gently, meanwhile, use tweezers to pull those two cable sets out of joint 6.

Figure 15,16. Overview of Joint 6

4. Disassembly Procedures (Joint 6)



Figure 17. Joint 6 and back case



Figure 18. The rest of the robot

Joint 6
Remove complete.

Next step:
Joint 6 Assembly

5. Assembly Procedures (Joint 6)



Figure 19. Prepare a new joint 6



Figure 20. The rest of the robot and joint 6



Figure 21. Picking cables from the bottom of joint 6

1. Prepare a new joint 6, use tweezers to pick the two cable sets of joint 5 through joint 6 bottom.

5. Assembly Procedures (Joint 6)




Figure 22. Joint 6 cable connection



Figure 23. Close-up of joint 5




Figure 24. Close-up of joint 6 bottom



Figure 25. Twist joint 6 to assemble

2. Plug in CANBUS cable connector and power cables, use 2mm Slotted Screwdriver to tighten the power cable.
3. Cover base with new joint 6 with extra caution. (**Warning:** Use tweezers to pull cables to prevent any cable from being squeezed by the structure)
4. Twist joint 6 until the structure at figure 23 and figure 24 are perfectly together.


5. Assembly Procedures (Joint 6)



4. Use 5.5mm Open-end Wrench to tighten (with a small torque, to protect bolts) bolts at the junction. (Ten bolts in total)
5. Use tweezers to cover the junction with rubber band.

Figure 26,27. Joint 6 overview

5. Assembly Procedures (Joint 6)




1. Mount the Joint back case
2. Use 2.5mm Allen wrench to tighten screws no. 1 to no.4.
3. Use 2.5mm Allen wrench to tighten limit screw no. 5.

Figure 28. Overview of Joint 6 (with back case)

Joint 6 assembly Complete
Next step, End-Effector assembly

5. Assembly Procedures (end-effector)



Regular End-effector

Figure 29. Prepare a new end - effector

1. Prepare an end-effector, plug in power cable connector and CANBUS cable connector shown as figure 31.




Figure 30. Overview of the robot body




Figure 31. Overview of Joint 6 and end - effector

5. Assembly Procedures



Figure 32. Close-up of joint 6




Figure 33. Close-up of end-effector




Figure 34. Joint 6 and end-effector assembly

-
2. Cover base with new end-effector with extra caution. (**Warning:** Use tweezers to pull cables to prevent any cable from being squeezed by the structure)
3. Rotate end-effector until the structure at figure 32 and figure 33 are perfectly together

5. Assembly Procedures




Figure 35,36. Joint 6 and end-effector junction overview

4. Use 5.5mm Open-end Wrench to tighten (with a small torque, to protect bolts) bolts at the junction. (Ten bolts in total);
5. Use 2.5mm Allen Wrench tighten limit screw;
6. Use tweezers to cover the junction with rubber band.

End-effector assembly complete

Joint 6 replacement complete

Thank You For Watching!